



 CHF100A series inverter used on the center air conditioner



The difference of effluent temperature and backwater temperature of the water-cycling system in the central air-conditioning indicates the heat exchanger of the whole system needed. So, we can control the flow of water-cycling to control the heat exchange speed based on the difference, it is the first choice control mode for energy saving.



*Your trusted industry automation solution provider*



SHENZHEN INVT ELECTRIC CO., LTD.

Service line: 86-755-86312859 E-mail: overseas@invt.com.cn

No.4 Building, Gaofa Scientific Industrial Park, Longjing, Nanshan District, Shenzhen, China

Industrial Automation:

- Frequency Inverter
- Servo & Motion Control
- Intelligent Elevator Control System
- Motor & Electric Spindle
- PLC

Electric Power:

- HMI
- SVG
- UPS
- Online Energy Management System
- Solar Inverter

INVT Copyright.

Information may be subject to change without notice during product improving.



201502(V4.0)

## Selection Guide

Model NO.	Rated Power(kW)	Rated Input Current(A)	Rated Output Current(A)	Size
<b>1AC 220V ±15%</b>				
CHF100A-1R5G-S2	1.5	14.2	7.0	B
CHF100A-2R2G-S2	2.2	23.0	10	B
<b>3AC 220V ±15%</b>				
CHF100A-0R7G-2	0.75	5.0	4.5	B
CHF100A-1R5G-2	1.5	7.7	7	B
CHF100A-2R2G-2	2.2	11.0	10	B
CHF100A-004G-2	4.0	17.0	16	C
CHF100A-5R5G-2	5.5	21.0	20	C
CHF100A-7R5G-2	7.5	31.0	30	D
CHF100A-011G-2	11.0	43.0	42	E
CHF100A-015G-2	15.0	56.0	55	E
CHF100A-018G-2	18.5	71.0	70	E
CHF100A-022G-2	22.0	81.0	80	F
CHF100A-030G-2	30.0	112.0	110	F
CHF100A-037G-2	37.0	132.0	130	F
CHF100A-045G-2	45.0	163.0	160	G
CHF100A-055G-2	55.0	181.0	190	G
<b>3AC 380V ±15%</b>				
CHF100A-1R5G/2R2P-4	1.5	5	3.7	B
CHF100A-2R2G/004P-4	2.2	5.8	5	B
CHF100A-004G/5R5P-4	4.0/5.5	10/15	9/13	C
CHF100A-5R5G/7R5P-4	5.5/7.5	15/20	13/17	C
CHF100A-7R5G/011P-4	7.5/11	20/26	17/25	D
CHF100A-011G/015P-4	11/15	26/35	25/32	D
CHF100A-015G/018P-4	15/18.5	35/38	32/37	D
CHF100A-018G/022P-4	18.5/22	38/46	37/45	E
CHF100A-022G/030P-4	22/30	46/62	45/60	E
CHF100A-030G/037P-4	30/37	62/76	60/75	E
CHF100A-037G/045P-4	37/45	76/90	75/90	F
CHF100A-045G/055P-4	45/55	90/105	90/110	F
CHF100A-055G/075P-4	55/75	105/140	110/150	F
CHF100A-075G/090P-4	75/90	140/160	150/176	G
CHF100A-090G/110P-4	90/110	160/210	176/210	G
CHF100A-110G/132P-4	110/132	210/240	210/250	G
CHF100A-132G/160P-4	132/160	240/290	250/300	H
CHF100A-160G/185P-4	160/185	290/330	300/340	H
CHF100A-185G/200P-4	185/200	330/370	340/380	H
CHF100A-200G/220P-4	200/220	370/410	380/415	I
CHF100A-220G/250P-4	220/250	410/460	415/470	I
CHF100A-250G/280P-4	250/280	460/500	470/520	I
CHF100A-280G/315P-4	280/315	500/580	520/600	I
CHF100A-315G/350P-4	315/350	580/620	600/640	I
CHF100A-350G-4	350	620	640	2xI
CHF100A-400G-4	400	670	690	2xI
CHF100A-500G-4	500	835	860	2xI
CHF100A-560G-4	560	920	950	2xI

## Technical Features

<b>I/O Features</b>	Input Voltage Range	380/220V±15%
	Input Frequency Range	47~63Hz
	Output Voltage Range	0~rated input voltage
	Output Frequency Range	0~400Hz
<b>I/O Terminals</b>	Input Terminals	programmable DI:7, 1 high speed pulse; programmable AI:2, AI1: -10V~10V; AI2: 0~10V or 0~20mA;
	Output Terminals	programmable open collector output:1(open collector or high speed pulse output selectable); programmable relay output:2 programmable AI:2, 0/4~20mA or 0~10V selectable.
	Communication Terminals	provide RS485 communication interface, adopt Modbus-RTU communication mode.
	Control Mode	V/F control, sensorless vector control (SVC)
	Speed Adjusting Range	1:100(SVC)
	Overload Capacity	150% rated current 60s, 180% rated current 10s .
	Frequency Reference Source	Keypad, analog input, HDI, serial communication, multi-step speed, simple PLC and PID. The combination of multi- modes and the switch between different modes can be realized.
<b>Control Function</b>	Other Functions	<ul style="list-style-type: none"> <li>Traverse Control Function</li> <li>PID Control Function</li> <li>Simple PLC, Multi-Steps Speed Control Function: 16 steps speed can be set.</li> <li>None-Stop when instantaneous power off.</li> <li>Speed Trace Function: Smoothly start the running motor.</li> <li>Automatic Voltage Regulation Function (AVR):</li> <li>Up to 23 fault protections: over current, over voltage, under voltage, over temperature, phase failure, overload etc.</li> </ul>
	Man-machine Interface	<p>LED Display</p> <p>Can display: setting frequency, output frequency, output voltage, output current etc.</p> <p>Multi-function Key-press</p> <p>The QUICK/JOG key-press can be used as multi-function key-press.</p>
<b>EMC</b>	EMC Criterion	<p>if the installing and wiring of the inverter together with the EMI filter according to « Manual of CHF100A », we can promise it's must meet the following criterion:</p> <ul style="list-style-type: none"> <li>EN61000-6-4</li> <li>EN61800-3</li> </ul> <p>[Normally, if the cable of motor is longer than 50m, it's should install AC reactor or sinusoidal filter at the output side of the inverter.]</p>
	Environmental Constraint	<p>Temperature</p> <p>-10°C ~ +40°C. Inverter will be derated if ambient temperature exceeds 40°C.</p> <p>Humidity</p> <p>≤90%, without condensation</p> <p>Altitude</p> <p>≤1000M, output rated power &gt;1000M, output power with derating</p> <p>Impingement and Oscillation</p> <p>The inverter is prohibited to drop on the floor or with suddenly impact, it also prohibited to be installed at the place where the oscillation may occur very probably.</p> <p>Electromagnetic Radiation</p> <p>The inverter is prohibited to be installed at the place where stronger electromagnetic radiation may occur very probably.</p> <p>Store Environment</p> <p>The inverter is prohibited to be stored at the place where with direct sunlight, fall of oil mist, steam and with heavy oscillation.</p>

## Wiring diagram of CHF100A series inverter

